



Descaling cartridge

Quick and efficient descaling of the Kärcher SC 3 EasyFix steam cleaner. All you need to do is insert the cartridge, and you're done.

1 Automatic indicator lamp for cartridge replacement

- The indicator lights up once the service life of the descaling cartridge has expired.

2 Simple and quick cartridge replacement

- Simply replace the cartridge and press the reset button on the device.



Descaling cartridge

Technical data

Order no.		2.863-018.0
EAN code		4054278026213
Weight	kg	0.14
Weight incl. packaging	kg	0.14
Dimensions (L × W × H)	mm	55 × 55 × 162